


**LaserLink<sup>®</sup> LLNTR**  
**Fiber Optic Transmitter**  
**1550nm, 5-210 MHz**  
INSTALLATION AND OPERATION  
MANUAL



(This page intentionally left blank)

# **LaserLink<sup>®</sup> LLNTR**

## **Fiber Optic Transmitter**

### **1550nm, 5-210 MHz**

#### **INSTALLATION AND OPERATION MANUAL**

Data, drawings and other material contained herein are proprietary to ANTEC Network Technologies and may not be reproduced or duplicated in any form without the prior written permission of ANTEC Network Technologies.

When ordering parts from ANTEC Network Technologies, be sure to include the equipment model number, equipment serial number and a description of the part.

In all correspondence with ANTEC Network Technologies regarding this publication, please refer to:

70285  
First Edition –12/98

© 1998 by ANTEC Network Technologies.  
All rights reserved. No part of this book may be reproduced in any form or by any means, without permission in writing from ANTEC Network Technologies.

**(This Page Intentionally Left Blank)**

# Table of Contents

---

<b>Chapter 1 General Information.....</b>	<b>1-1</b>
Overview.....	1-1
How to Contact ANTEC Network Technologies.....	1-2
We Welcome Your Comments.....	1-3
Safety.....	1-4
Equipment Description.....	1-10
Equipment Specifications.....	1-13
List of Abbreviations.....	1-15

---

<b>Chapter 2 Installation.....</b>	<b>2-1</b>
Overview.....	2-1
<b>Section A Preparing for Installation.....</b>	<b>2-A-1</b>
Overview.....	2-A-1
Unpacking.....	2-A-2
Inspection.....	2-A-3
How to Return Equipment.....	2-A-4
Recommended Tools and Equipment.....	2-A-6
<b>Section B Installing the LLNTR.....</b>	<b>2-B-1</b>
Installation.....	2-B-1
<b>Section C Care and Cleaning of Optical Connectors.....</b>	<b>2-C-1</b>
Overview.....	2-C-1
Cleaning.....	2-C-3

---

*Continued on next page*

## Table of Contents - continued

---

<b>Chapter 3 Setup and Operation .....</b>	<b>3-1</b>
Overview.....	3-1
<b>Section A Activating the LLNTR.....</b>	<b>3-A-1</b>
Activation.....	3-A-1
<b>Section B Controls and Indicators.....</b>	<b>3-B-1</b>
Overview.....	3-B-1
Front Panel Controls and Indicators.....	3-B-2
Rear Panel Connectors .....	3-B-4
<b>Section C Status Monitoring .....</b>	<b>3-C-1</b>
Overview.....	3-C-1
User Panel .....	3-C-2
EMIC.....	3-C-3
Third Party .....	3-C-4
<b>Section D Troubleshooting.....</b>	<b>3-D-1</b>
Troubleshooting .....	3-D-1

---

# Chapter 1

## General Information

### Overview

---

**Introduction** This manual describes installation and operation of the Laser Link<sup>®</sup> Narrowcast Return Transmitter (LLNTR).

---

**Manual Contents** This manual contains three chapters.

- Chapter 1 - General Information
- Chapter 2 - Installation
- Chapter 3 - Setup and Operation

---

**How to Use this Manual** This manual is divided into the chapters listed above. Major topics in each chapter are listed at the beginning of the chapter. Use these lists to find the desired information.

---

**In this Chapter** This chapter contains these major topics.

<b>Topic</b>	<b>See Page</b>
How to Contact ANTEC Network Technologies	1-2
We Welcome Your Comments	1-3
Safety	1-4
Equipment Description	1-10
Equipment Specifications	1-13
List of Abbreviations	1-15

---

## How to Contact ANTEC Network Technologies

---

**Overview** ANTEC Network Technologies is ready to assist you as necessary.

---

**How to Contact ANTEC Network Technologies** Here's how to contact us.

<b>In the USA . . .</b>	<b>Outside the USA . . .</b>
By phone, call 1-800-FIBERME and follow the voice prompts.  By mail, write to: ANTEC Network Technologies Attention: Technical Service 11450 Technology Circle Duluth, GA 30097	Contact your ANTEC Network Technologies sales office for assistance. Sales offices are listed on the back cover of this manual.

---

## We Welcome Your Comments

---

**Overview** We welcome your comments on this manual. User comments are an important source of ideas to improve our manuals.

---

**How to Comment** You can contact us by mail or e-mail.

<b>By Mail . . .</b>	<b>By E-mail:</b>
Write to:  ANTEC Network Technologies Attention: Technical Publications 11450 Technology Circle Duluth, GA 30097	Send a message to:  <b>tech.pubs@antec.com</b>

---

## Safety

**Overview** Safety of personnel is the primary concern during all procedures.

This section describes typical safety considerations. All of them may not apply to you or your installation/operation environment.

**Additional Requirements** Your organization may have additional safety requirements. These recommendations in no way supersede any safety requirements of your organization.

**Admonishments** Dangers, warnings, cautions and notes appear in the text immediately before the procedure step or other text to which they apply. Observe all these admonishments. The table below describes each category of admonishment.

Admonishment Category	Description
DANGER	DANGER refers to a situation hazardous to personnel if the information in the DANGER is not observed. Possible consequences are severe injury or death.
WARNING	WARNING refers to a situation in which customer service may be interrupted if the WARNING is not observed.
CAUTION	CAUTION refers to a situation in which equipment may be damaged if the CAUTION is not observed.
NOTE	NOTE highlights critical information about a procedure or description. A NOTE does not describe hazards to personnel, equipment or service.

*Continued on next page*

## Safety, Continued

**Admonishment Symbols** A graphic symbol and title denote each type of admonishment. The table below lists typical admonishments, their graphic symbol and meaning. All of these admonishments may not be used in this manual.

Admonishment	Graphic Symbol	Meaning
DANGER		Electrical hazard.
DANGER		Laser light hazard.
DANGER		Lifting object hazard.
DANGER		Mechanical hazard.
DANGER		Chemical Hazard
WARNING		Possible interruption of customer service.
CAUTION		Possible damage to equipment.
NOTE	none	Highlights critical information. No personnel or equipment hazards.

*Continued on next page*

## Safety, Continued

---

**Emergency Plan** Have an emergency plan. Know the procedures for obtaining first-aid and firefighting assistance. Plan your work and maintain good housekeeping. Your safety and the quality of the product depend on it.

---

**Resuscitation** Personnel working with or near hazardous voltages or chemicals should be familiar with modern methods of resuscitation.

---

**Electrical Safety Summary** These are general electrical safety precautions that are not related to any specific procedure. These are recommended precautions that personnel should understand and apply.

---

### Electrical Danger



---

**Avoid shorting circuits when using metal tools. Some circuits have high current capability. When shorted, these circuits will flash and may cause burns or eye injury.**

**Remove all jewelry and exposed metal objects from body and clothing before performing maintenance, adjustments or troubleshooting. Before working inside the equipment, remove all power unless power is required to perform the procedure.**

**Failure to observe these dangers may result in death or severe injury.**

---

*Continued on next page*

## Safety, Continued

---

### Electrical Danger - continued



---

**Replacement of fuses or other parts must be with identical types and ratings. Substitution of non-identical parts may cause safety and fire hazards.**

**Servicing this equipment may require working with protective covers removed and ac power connected. Use extreme caution during these procedures.**

**Failure to observe these dangers may result in death or severe injury.**

---

### Mechanical Safety Summary

These are general mechanical safety precautions that are not related to any specific procedure. These are recommended precautions that personnel should understand and apply.

---

### Mechanical Danger



---

**Overhead hazards, either because items may fall or because personnel may strike them unintentionally, are typical around industrial sites. Never stand underneath anything while it is hoisted. Always wear a hard hat, especially if someone is above you.**

**Failure to observe this danger may result in death or severe injury.**

---

*Continued on next page*

## Safety, Continued

---

### Laser Safety Summary

These are general safety precautions associated with a class 1B laser. They are not related to any specific procedure. These are recommended precautions that personnel must understand and apply.

Radiation from semiconductor laser diodes feeding this detector may be sufficiently intensive to cause almost instantaneous damage to the eye. Consider each application hazardous until proven safe. Carefully consider power emitted, radiation angle of divergence or confinement of radiation within optical fibers or other physical constraints. Since the radiation is in the non visible (infra red) portion of the spectrum, take precautions to avoid the accidental viewing of the light source.

---

### Laser Danger



---

**Laser hazard. This product contains a class 1B laser with no safety interlocks. Under no circumstances should connectors be viewed with equipment enabled. Direct viewing of connectors can cause eye damage.**

**Failure to adhere to this danger may result in serious injury to the eye(s) or even blindness.**


---

*Continued on next page*

## Safety, Continued

### Labels

A safety label is affixed to this equipment in plain view. The safety label is shown below.



## Equipment Description

---

**Overview** This section contains a high-level physical and functional description of the LLNTR.

LLNTR features are listed below:

- Front Panel Accessible Test Points      Optical Output Power (1 V dc/10mW)  
RF Laser Drive Level (-30dB)
- Front Panel Accessible Controls      Power on/off key switch.  
Attenuation Adjust (-8 to +2 dB min.)
- Front Panel Accessible Indicators      Green/Red power LED  
Green/Red optical power status LED  
Green/Red laser temperature status LED  
Green/Red laser bias status LED  
Green/Red fan status LED
- Front panel mounted SC/APC connector

---


**Physical Description** The LLNTR consists of a metal chassis and internal electrical and optical components. The chassis installs into a Laser Link II Mainframe.

---


*Continued on next page*

## Equipment Description, Continued

**Diagram** The diagram below illustrates the LLNTR



**Functional Diagram** The diagram below shows how the LLNTR functions.



*Continued on next page*

## Equipment Description, Continued

---

### Functional Description

Refer to the LLNTR functional diagram. The RF input requires a nominal 32 dBmV/channel signal for 6 channel loading. This signal is amplified and then passed through a variable attenuator circuit. The variable attenuator has a range of -8 to +2 dB and is controlled by a front panel potentiometer.

The output of the attenuator is coupled to the laser board and to a calibrated -30 dB test point mounted on the front panel. The RF signal is applied to the laser board where it modulates the light source for transmission over the output fiber.

The laser board consists of a DFB laser diode package. A laser monitor circuit provides constant temperature and output power control of the diode package over the full range of ambient temperature. This monitor circuit also provides a calibrated 1V dc/10 mW optical power test point to the front panel, controls the front panel optical power, laser temperature and laser bias status LEDs. It also provides analog signals and alarms to the telemetry connector on the Laser Link II Mainframe.

The A/B power select circuit is an integral part of the LLNTR. In the event of a failure of the primary power supply, an optional redundant power supply wired to the Laser Link power distribution board can provide power to the LLNTR automatically. The POWER LED on the front panel displays power status. During normal operation, the LED is green. It is red when the +24V A supply (primary) has failed and power is supplied by the +24V B supply (backup). The LED is off when the LLNTR receives no power.

The LLNTR also provides power alarms and status indicators to the Laser Link user panel or the Element Management Interface Card (EMIC). The Laser Link EMIC collects the vital signs signals from the modules in the Laser Link II Mainframe and provides the communications interface between the mainframe and the Track Link™ Element Management System.

The Laser Link II Mainframe user panel receives information from the LLNTR through the mainframe general operational alarm (GOALN). The alarm LED on the mainframe turns red if any of the following occur: redundant power supply is selected; optical output power drops by 25%; laser temperature is out-of-range; laser bias is out-of-range; or fan failure.

---

## Equipment Specifications

**Overview** This section describes specifications of the LLNTR.

### Optical Specifications

The table below lists optical specifications.

Characteristic	Specification
Output power	+9 ±1 dBm
Connector return loss	≥65 dB SC/APC
Wavelength	1560.61 ±0.1 nm 1558.98 ±0.1 nm 1557.36 ±0.1 nm 1555.75 ±0.1 nm 1554.13 ±0.1 nm 1552.52 ±0.1 nm 1550.92 ±0.1 nm 1549.32 ±0.1 nm

### RF Specifications

The table below lists RF specifications.

Characteristic	Specification
Input and test point impedances	75 Ohms
Frequency range	5-210 MHz
Flatness	±0.75 dB
Input and test point return losses	≥14 dB
Input level	+32 dBmV per channel <sup>1,5</sup>
Level adjustment	-8 to +2 dB
Test point level	-30 ±1 dB <sup>6</sup>
CNR	≥49 dB <sup>1,2</sup>
CSO	≤ -48 dB <sup>1,2</sup>

*Continued on next page*

## Equipment Specifications, Continued

### RF Specifications (continued)

Characteristic	Specification
CTB	$\leq -59$ dB <sup>1,2</sup>
NPR dynamic range	15 dB for 35 MHz <sup>2,3,7</sup>
Crosstalk	$\geq 40$ dB <sup>4</sup>
Notes:	
<ol style="list-style-type: none"> <li>1. Six CW carriers. 7, 13, 19, 25, 31 and 37 MHz</li> <li>2. Optical path 10 dB fiber, 6 dB passive. Receiver: LLDR</li> <li>3. Estimated input dynamic range levels for 35 MHz noise load: -45 to -29 dBmV/Hz</li> <li>4. 8 optical channels launched into 10 dB of fiber at 7 dBm</li> <li>5. Performance estimates based on 10% <math>\pm</math>1% OMI</li> <li>6. Relative to laser drive level</li> <li>7. At 40 dB NPR level</li> </ol>	

### Power Specifications

The table below lists power specifications.

Characteristic	Specification
Input power	+24 V dc provided by Laser Link II Mainframe
Power consumption	20 W maximum
Current drain	850 mA maximum

### Physical Specifications

The table below lists physical specifications.

Characteristic	Specification
Operating temperature	32 to 122 °F (0 to 50 °C)
Relative humidity	5 to 95%, non-condensing
Optical connector	SC/APC
Mounting	Requires Laser Link II Mainframe
Dimensions	Height: 5.21 in (13.2 cm) Width: 2.17 in (5.5 cm) Depth 13.5 in (34.3 cm)
Weight	2.19 lb (1 kg)

## List of Abbreviations

**Overview** This table lists non-standard abbreviations in this manual.

### Abbreviations

<b>Abbreviation</b>	<b>Definition</b>
CDM	companded delta modulation
C/N	carrier-to-noise
CNR	Carrier to noise ratio
CSO	composite second order
CTB	composite triple beat
dB	decibel
dBm	decibel referenced to 1 milliwatt
dBmV	decibel-millivolt
DC	directional coupler
DFB	distributed feedback
DSO	discrete second order
EMIC	Element management interface card
EQ	equalizer
FDM	frequency division multiplex
GOALN	Global alarm
LLDR	Laser Link Reverse Data Receiver
LLNTR	Laser Link Narrowcast Return Transmitter
NPR	Noise power ratio
nsec	nanosecond
NTSC	National Television Standards Committee
RDL	non-cooled, Fabry-Perot data laser
RDU	non-cooled/isolated distributed feedback laser
RVD	cooled/isolated distributed feedback laser
RVL	cooled Fabry-Perot video laser
RR	return for repair
RRU	reverse receiver unit

(This Page Intentionally Blank)

**\*\*END OF CHAPTER\*\***

# Chapter 2 Installation

## Overview

---

**Introduction** This chapter describes installation of the Laser Link Narrowcast Return Transmitter (LLNTR).

---

**In this Chapter** This chapter contains these sections.

<b>Topic</b>	<b>See Section</b>
Preparing for Installation	A
Installing the LLNTR	B
Care and Cleaning of Optical Connectors	C

---

(This Page Intentionally Blank)

# Section A

## Preparing for Installation

### Overview

---

**Introduction** This section describes preparing to install the LLNTR.

---

**In this Section** This section contains the following topics.

Topic	See Page
Unpacking	2-A-2
Inspection	2-A-3
How to Return Equipment	2-A-4
Recommended Tools and Equipment	2-A-6

---

## Unpacking

---

**Overview** ANTEC Network Technologies thoroughly inspects and carefully packs all equipment before shipment. At the time of shipment, the carrier assumes responsibility for its safe delivery; therefore, do not return damaged units to ANTEC Network Technologies.

---

**Procedure** Unpack the LLNTR according to the procedure below.

<b>Step</b>	<b>Action</b>
1	Inspect shipping carton for visible damage.
2	Open the shipping carton. (Do not destroy shipping cartons until installation is complete.)
3	Remove all packing material.
4	Inspect unit for visible damage.
5	Using packing list, check for missing items (see "How To Inventory Equipment Received").

---

## Inspection

### What to do about Visible Loss or Damage

Report visible loss or damage as follows.

#### NOTE

Failure to adequately describe external evidence of loss or damage may result in the carrier refusing to honor a damage claim.

Step	Action
1	Obtain a claim form from the carrier.
2	Make a note of any loss or evidence of external damage on the freight bill or receipt.
3	Have freight bill or receipt signed by the carrier's agent

### What to do about Concealed Damage

Concealed damage is not apparent until after unpacking. The contents may be damaged in transit due to rough handling even though the carton may not show external damage. The carrier is responsible for hidden damage caused in transit. If you follow these instructions carefully, ANTEC Network Technologies guarantees its full support of your claims to protect you against loss from concealed damage.

Step	Action
1	If you discover damage after unpacking, make a written request for inspection by the carrier's agent within 15 days of delivery date.
2	File any claims with the carrier, not ANTEC Network Technologies.

### How to Inventory Equipment

Follow this procedure to inventory equipment.

Step	Action
1	Check off each item received against the list on the packing slip included with the shipment.
2	Verify this list matches the purchase order.
3	If any items are missing, please notify ANTEC Network Technologies immediately by calling 1-800-FIBERME (in the US) or calling your local sales office (outside of the US)..
4	Return a copy of the packing slip with the missing item(s) circled.

## How to Return Equipment

**Overview** ANTEC Network Technologies makes every effort to ensure parts and equipment arrive in working condition. Occasionally, it may be necessary to return parts or equipment that are not in working condition.

**Procedure** Follow this procedure to return equipment.

Step	Action				
1	Contact ANTEC Network Technologies . . . <table border="1" data-bbox="565 688 1385 877"> <thead> <tr> <th data-bbox="565 688 976 724">In the US</th> <th data-bbox="976 688 1385 724">Outside the US</th> </tr> </thead> <tbody> <tr> <td data-bbox="565 724 976 877">By phone, call 1-800-FIBERME and follow the voice prompts.</td> <td data-bbox="976 724 1385 877">Contact your sales office for assistance. Sales offices are listed on the back cover of this manual.</td> </tr> </tbody> </table>	In the US	Outside the US	By phone, call 1-800-FIBERME and follow the voice prompts.	Contact your sales office for assistance. Sales offices are listed on the back cover of this manual.
In the US	Outside the US				
By phone, call 1-800-FIBERME and follow the voice prompts.	Contact your sales office for assistance. Sales offices are listed on the back cover of this manual.				
2	Tag or otherwise identify the defective equipment. Be sure to write the RR number on the tag.				
3	If possible, please reference the sales order, purchase order, and date the equipment was received.				
4	<div style="text-align: center;">  <b>CAUTION</b> </div> <hr/> <p><b>Do not use Styrofoam chips (peanuts). Use of Styrofoam chips (peanuts) will void the warranty.</b></p> <hr/> <p>Pack the equipment in the original container and protective packing material, if possible. If the original packing material is not available, use a sturdy corrugated box and appropriate protective packing material.</p>				

*Continued on next page*

## How to Return Equipment, Continued

---

### Procedure (continued)

Step	Action
5	Be sure to include this information: Your Name Company Name Street Address City, State, Country and Zip/Postal Code Telephone Number RR Number Problem Description
6	<p style="text-align: center;"><b>NOTE</b></p> <hr style="width: 50%; margin: auto;"/> <p style="text-align: center;">Ship equipment prepaid. ANTEC Network Technologies will not accept freight collect.</p> <hr style="width: 50%; margin: auto;"/> <p>Ship equipment to ANTEC Network Technologies as directed by Customer Service.</p>

---

## Recommended Tools and Equipment

**Tools and  
Equipment**

---

These recommended tools and equipment are required for installation.

<b>Quantity</b>	<b>Description</b>
1	1/4-inch flat-blade screwdriver
1	Optical connector cleaning supplies

---

# Section B

## Installing the LLNTR

### Installation

---

**Introduction** This section describes installing the LLNTR.

The LLNTR is shipped assembled with the exception of the 15-pin male-to-female shielded cable assembly and keys for the ON/OFF switch.

Install the LLNTR in any slot, one through seven, of the mainframe. After installation, refer to the procedures in Chapter 3, Setup and Operation, to activate the LLNTR.

---

**Procedure** Follow this procedure to install the LLNTR.

Step	Action
1	<div data-bbox="857 1003 1097 1083" style="text-align: center;"> <b>CAUTION</b></div> <hr/> <p data-bbox="699 1119 1230 1415"><b>Static sensitive devices. Always wear a properly grounded wrist strap when working on this equipment. The shelf has a grounding jack that may be used to plug the wrist strap into. Failure to observe this caution may result in equipment damage or premature equipment failure.</b></p> <hr/> <p data-bbox="548 1499 1365 1560">Open the front cover of the mainframe by turning the front panel latch handles counterclockwise.</p>

*Continued on next page*

## Installation, Continued

### Procedure (continued)

Step	Action
2	<p style="text-align: center;"><b>NOTE</b></p> <hr/> <p style="text-align: center;"><b>When installing in a mainframe bay that is equipped with 14 rails, remove the rail in the “B” position to accommodate the LLNTR.</b></p> <hr/> <p>Carefully insert the LLNTR into an empty slot of the Laser Link II Mainframe. Align the flange on the top and bottom of the LLNTR with the top and bottom slide rail on the mainframe.</p>
3	Locate the optical connector mounted on the front panel. Clean the connector as described in Care and Cleaning of Fiber Optic Connectors.
4	Secure the LLNTR in the shelf with the two captive screws located on the top of the LLNTR front face plate. The screws are provided with the LLNTR.
5	Connect the 15-pin D-type shielded cable assembly: <ul style="list-style-type: none"> <li>• one end to the connector labeled POWER on the rear of the LLNTR.</li> <li>• other end to the connector on the power distribution board of the mainframe, J1- J7.</li> </ul>
6	Secure both cable connectors with screws.
7	Verify shelf power is on and turn the key switch of the LLNTR to the ON position.
8	Verify that the POWER and LASER STATUS LEDs are green before proceeding. Note that while the LLNTR is stabilizing during initial startup, the LASER STATUS LED will be red
9	Turn the key switch to the OFF position.
10	Clean outgoing fiber connector as described in Care and Cleaning of Fiber Optic Connectors.
11	Connect the LLNTR to the outgoing fiber connector.
12	Continue to Chapter 3 to activate the LLNTR.

# Section C

## Care and Cleaning of Optical Connectors

### Overview

---

**Introduction** Fiber optic connectors are cleaned at assembly, but require recleaning when the equipment is installed. Both the connector attached to the bulkhead adapter in the equipment and the jumper connector that will be attached to the bulkhead adapter must be cleaned. This section describes recommended cleaning instructions for both halves of the connection.

---

**Guidelines** Proper care and cleaning of optical connectors is critical to equipment operation. Follow these guidelines when working with optical connectors.



---

**Laser light hazard. Never look into the end of an optical fiber or connector. Use an indirect image-converting device such as the “Find-R-Scope.” Failure to observe this danger can result in eye damage or blindness.**

---

- The working surfaces of optical connectors are highly-polished and designed for precision alignment. Keep them microscopically-clean and free of scratches.
- Optical power readings and signal quality can seriously degrade if optical connectors or bulkheads are mishandled or allowed to become dirty.
- Optical bulkheads on transmitters and receivers and the connector faces of optical cables are shipped with protective caps. Do not remove caps until ready to make connections.
- Do not touch unprotected optical connector faces. Do not allow dirt to touch the connector or the bulkheads. Small scratches, minute traces of dirt or skin oils can degrade signal quality.

---

*Continued on next page*

## Overview, Continued

---

### **Consumable Materials**

These consumable materials are required for the cleaning procedure.

- Lint Free Wipes (tissues)
  - Ethyl or Isopropyl Alcohol, >91% purity (Do not use a lesser grade. Do not use common rubbing alcohol.)
  - Filtered Canned Air
  - Lint Free Swabs
-

# Cleaning

## Overview

This section describes cleaning two types of optical connectors:

- Connectors installed in a bulkhead adapter
- Connectors not installed in a bulkhead adapter

## Cleaning of Connectors in a Bulkhead Adapter

Follow this procedure to clean optical connectors installed in an equipment bulkhead adapter.

Step	Action						
1	Remove protective cap from bulkhead connector.						
2	<p>Blow dust particles from the interior surface of the bulkhead adapter using filtered canned air as follows:</p> <div style="text-align: center;">  <b>CAUTION</b> </div> <hr/> <p><b>Be sure to hold air can in upright position so that liquid from the can cannot enter the air tube. Do not shake the can. Do not blow air directly on the fiber. Failure to observe this caution may damage the connector or cause contaminates to be placed on the surface being cleaned.</b></p> <hr/> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Step</th> <th>Action</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.</td> </tr> <tr> <td>2</td> <td>Gently blow into the adapter.</td> </tr> </tbody> </table>	Step	Action	1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.	2	Gently blow into the adapter.
Step	Action						
1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.						
2	Gently blow into the adapter.						

*Continued on next page*

## Cleaning, Continued

### Cleaning of Connectors in a Bulkhead Adapter (continued)

Step	Action												
3	<p data-bbox="544 468 1312 499">Swab the bulkhead adapter using a lint-free swab as follows:</p> <div data-bbox="842 533 1081 613" style="text-align: center;">  <b>CAUTION</b> </div> <hr data-bbox="659 632 1248 636"/> <p data-bbox="662 648 1239 791"><b>Do not use alcohol less than 91% pure. Do not use common rubbing alcohol. Failure to observe this caution will deposit contaminates on the fiber surface.</b></p> <hr data-bbox="659 800 1248 804"/> <table border="1" data-bbox="566 873 1365 1262" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th data-bbox="574 877 667 919">Step</th> <th data-bbox="667 877 1365 919">Action</th> </tr> </thead> <tbody> <tr> <td data-bbox="574 919 667 993">1</td> <td data-bbox="667 919 1365 993">Moisten a lint-free swab with &gt;91% pure ethyl or isopropyl alcohol.</td> </tr> <tr> <td data-bbox="574 993 667 1066">2</td> <td data-bbox="667 993 1365 1066">Insert the moistened swab into the bulkhead adapter until it touches the interior connector face.</td> </tr> <tr> <td data-bbox="574 1066 667 1140">3</td> <td data-bbox="667 1066 1365 1140">Apply light pressure and rotate the swab approximately eight to ten turns.</td> </tr> <tr> <td data-bbox="574 1140 667 1182">4</td> <td data-bbox="667 1140 1365 1182">Remove the swab.</td> </tr> <tr> <td data-bbox="574 1182 667 1262">5</td> <td data-bbox="667 1182 1365 1262">Insert a dry lint-free swab and gently turn several times.</td> </tr> </tbody> </table>	Step	Action	1	Moisten a lint-free swab with >91% pure ethyl or isopropyl alcohol.	2	Insert the moistened swab into the bulkhead adapter until it touches the interior connector face.	3	Apply light pressure and rotate the swab approximately eight to ten turns.	4	Remove the swab.	5	Insert a dry lint-free swab and gently turn several times.
Step	Action												
1	Moisten a lint-free swab with >91% pure ethyl or isopropyl alcohol.												
2	Insert the moistened swab into the bulkhead adapter until it touches the interior connector face.												
3	Apply light pressure and rotate the swab approximately eight to ten turns.												
4	Remove the swab.												
5	Insert a dry lint-free swab and gently turn several times.												

*Continued on next page*

## Cleaning, Continued

### Cleaning of Connectors in a Bulkhead Adapter(continued)

Step	Action						
4	<p data-bbox="544 470 1312 541">Blow dust particles from the interior surface of the bulkhead adapter using filtered canned air as follows:</p> <div data-bbox="841 573 1081 653" style="text-align: center;">  <b>CAUTION</b> </div> <hr data-bbox="659 674 1237 678"/> <p data-bbox="659 688 1224 982"><b>Be sure to hold air can in upright position so that liquid from the can cannot enter the air tube. Do not shake the can. Do not blow air directly on the fiber. Failure to observe this caution may damage the connector or cause contaminates to be placed on the surface being cleaned.</b></p> <hr data-bbox="659 991 1237 995"/> <table border="1" data-bbox="566 1064 1362 1260" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th data-bbox="571 1064 667 1102">Step</th> <th data-bbox="667 1064 1362 1102">Action</th> </tr> </thead> <tbody> <tr> <td data-bbox="571 1102 667 1220">1</td> <td data-bbox="667 1102 1362 1220">Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.</td> </tr> <tr> <td data-bbox="571 1220 667 1260">2</td> <td data-bbox="667 1220 1362 1260">Gently blow air into the adapter.</td> </tr> </tbody> </table>	Step	Action	1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.	2	Gently blow air into the adapter.
Step	Action						
1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.						
2	Gently blow air into the adapter.						
5	Insert a recently cleaned connector into the bulkhead adapter.						

*Continued on next page*

## Cleaning, Continued

### Cleaning of Connectors Not in a Bulkhead Adapter

Follow this procedure to clean optical connectors not installed in an equipment bulkhead adapter.

Step	Action
1	<p style="text-align: center;">NOTE</p> <hr/> <p style="text-align: center;">Do not reinstall protective cap after cleaning procedure. Protective caps are designed to protect the connector ferrule from damage, not to keep the connector clean.</p> <hr/> <p>Remove protective cap from bulkhead connector.</p>
2	<p style="text-align: center;"> CAUTION</p> <hr/> <p style="text-align: center;"><b>Avoid contamination of lint-free wipes. Handle wipes by the edges. Discard each wipe immediately after use. Failure to observe this caution may result in contaminates on the surface being cleaned.</b></p> <hr/> <p>Place a dry lint-free wipe on a solid surface.</p>
3	Place another dry lint-free wipe on top of the first wipe.
4	<p style="text-align: center;"> CAUTION</p> <hr/> <p style="text-align: center;"><b>Do not use alcohol less than 91% pure. Do not use common rubbing alcohol. Failure to observe this caution will deposit contaminates on the fiber surface.</b></p> <hr/> <p>Moisten the top wipe with &gt;91% pure ethyl or isopropyl alcohol.</p>

*Continued on next page*

## Cleaning, Continued

### Cleaning of Connectors Not in a Bulkhead Adapter (continued)

Step	Action						
5	Gently wipe the connector ferrule and endface. For APC connectors only, wipe with one continuous motion in the direction of the angle.						
6	Discard the wipes.						
7	Place a dry lint-free wipe on a solid surface and gently slide the connector endface across the wipe. For APC connectors only, wipe with one continuous motion in the direction of the angle.						
8	<p>Blow dust particles from connector using filtered canned air as follows:</p> <div style="text-align: center;">  <b>CAUTION</b> </div> <hr/> <p><b>Be sure to hold air can in upright position so that liquid from the can cannot enter the air tube. Do not shake the can. Do not blow air directly on the fiber. Failure to observe this caution may damage the connector or cause contaminates to be placed on the surface being cleaned.</b></p> <hr/> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Step</th> <th>Action</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.</td> </tr> <tr> <td>2</td> <td>Gently blow air across the connector end or surface to be cleaned.</td> </tr> </tbody> </table>	Step	Action	1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.	2	Gently blow air across the connector end or surface to be cleaned.
Step	Action						
1	Hold air can upright. Position the can extension tube approximately 6 in (15.3 cm) from the surface to be cleaned.						
2	Gently blow air across the connector end or surface to be cleaned.						
9	Promptly insert connector into cleaned bulkhead adapter.						

(This Page Intentionally Blank)

**\*\*END OF CHAPTER\*\***

# Chapter 3

## Setup and Operation

### Overview

---

**Introduction** This chapter describes how to set up and operate Laser Link Narrowcast Return Transmitter (LLNTR). These procedures assume the LLNTR is installed according to the procedures in Chapter 2 of this manual.

---

**In this Chapter** This chapter contains the following sections.

Topic	See Section
Activating the LLNTR	A
Controls and Indicators	B
Status Monitoring	C
Troubleshooting	D

---

(This Page Intentionally Blank)

## Section A

# Activating the LLNTR

## Activation

---

**Introduction** This section describes activating the LLNTR. Activation consists of connecting the RF input signal to the LLNTR. When the input signal is connected, the LLNTR automatically produces an optical output.

---

**RF Signal Input Check** Check the RF input signal with a spectrum analyzer prior to connecting the cable to the RF IN jack of the LLNTR. In the case of a 6 NTSC channel load, the laser drive level is optimized during manufacture to achieve the specified link performance of the LLNTR with an RF input level of 32 dBmV/channel.

After verifying the 32 dBmV/channel RF level, connect the 75-Ohm cable to the RF input port on the rear of the LLNTR.

---

(This Page Intentionally Blank)

## Section B Controls and Indicators

### Overview

---

**Introduction** This section describes the controls and indicators of the Laser Link Narrowcast Return Transmitter (LLNTR).

---

**In this Section** This section contains the following topics.


<b>Topic</b>	<b>See Page</b>
Front Panel Controls and Indicators	3-B-2
Rear Panel Connectors	3-B-4

---

## Front Panel Controls and Indicators

**Overview** The front panel of the Laser Link Narrowcast Return Transmitter (LLNTR) provides access to the optical and RF test points, RF attenuator and LED diagnostic indicators and the optical output connector.

**Diagram** This diagram shows the front panel of the LLNTR.



*Continued on next page*

## Front Panel Controls and Indicators, Continued

**Description** The table below describes the front panel controls and indicators.

Reference	Control/Indicator	Description
1	POWER LED	Displays status of power to the LLNTR: <ul style="list-style-type: none"> <li>• Green indicates normal operation of the +24 V dc primary power supply</li> <li>• Red indicates the LLNTR is powered by the +24 V dc backup supply</li> <li>• Off (not lit) indicates no power to the LLNTR.</li> </ul>
2	OPTICAL POWER LED	<ul style="list-style-type: none"> <li>• Green indicates normal operation</li> <li>• Red indicates optical power has dropped by &gt;25% of initial value.</li> </ul>
3	LASER TEMP LED	<ul style="list-style-type: none"> <li>• Green indicates normal operation</li> <li>• Red indicates laser temperature is out of range</li> </ul>
4	LASER BIAS LED	<ul style="list-style-type: none"> <li>• Green indicates normal operation</li> <li>• Red indicates laser bias current is out of range</li> </ul>
5	FAN LED	<ul style="list-style-type: none"> <li>• Green indicates normal operation</li> <li>• Red indicates fan failure</li> </ul>
6	RF ATTEN ADJUST	Provides –8 to +2 dB level adjustment to the laser RF drive level
7	OPTICAL POWER 1 V dc/10 mW	Optical power test point. Provides a scaled dc voltage of the LLNTR's optical output power. 1 V dc represents 10 mW of optical power at 1550 nm
8	OFF/ON Key Switch	Key switch turns power on and off to activate and deactivate the LLNTR
9	TEST -30 dB	A -30 dB sample of the laser RF drive level
10	SC Adapter	Optical output SC/APC connector


## Rear Panel Connectors

---

**Overview** The rear panel of the LLNTR provides access to the RF input connector and the power interface.

---

**Diagram** This diagram shows the rear panel of the LLNTR.



---

*Continued on next page*

## Rear Panel Connectors, Continued

**Description** The table below describes the rear panel controls and indicators.

Reference	Connector	Description
1	RF IN	RF input F-type connector
2	POWER	<p>15-pin D-type connector. Provides power and alarm connector to the Laser Link II Mainframe power distribution board.</p> <ul style="list-style-type: none"> <li>• Pin 1 - GND</li> <li>• Pin 2 - NC</li> <li>• Pin 3 - NC</li> <li>• Pin 4 - GOALN (general alarm)</li> <li>• Pin 5 - Redundant power alarm</li> <li>• Pin 6 - +24 V dc supply A</li> <li>• Pin 7 - +24 V dc supply B</li> <li>• Pin 8 - GND</li> <li>• Pin 9 - NC</li> <li>• Pin 10 - NC</li> <li>• Pin 11 - Optical output power calibrated 1 V/10 mW</li> <li>• Pin 12 - Laser bias current calibrated 1 V/50 mA</li> <li>• Pin 13 - LIM current limit alarm</li> <li>• Pin 14 - +24 V dc supply A</li> <li>• Pin 15 - GND</li> </ul>
3	FAN	4-pin connector. Allows fan removal.

(This Page Intentionally Blank)

# Section C

## Status Monitoring

### Overview

---

**Introduction** This section describes status monitoring for the LLNTR.

In addition to the front-panel LEDs, LLNTR vital parameters are also provided to the mainframe EMIC or user panel and to the mainframe telemetry port. Depending on the configuration purchased, the mainframe is shipped to the customer with either the EMIC or the user panel installed. Should the user desire to upgrade to the EMIC in the future, an upgrade kit is available. Refer to the Laser Link II Mainframe manual.

---

**In this Section** This section contains the following topics.

Topic	See Page
User Panel	3-C-2
EMIC	3-C-3
Third Party	3-C-4

---

## User Panel

---

### **Description**

The Laser Link user panel receives information from the LLNTR through the mainframe's general operation alarm, GOALN. The ALARM LED on the panel illuminates red to signal an alarm condition for any of the modules housed in the mainframe (transmitters, receivers, and amplifiers).

Conditions of the LLNTR which would trip this alarm include: operation by redundant power supply, laser temperature out of range, laser bias out of range, optical power output out of range (drop by 25%), and/or a fan failure.

---

## EMIC

---

### **Description**

The optional Element Management Interface Card (EMIC)

- collects the vital signs signals of the modules in a Laser Link II Mainframe
- provides the communications interface between the mainframe and the Track Link system (if used)

Parameters monitored by this system include: power supply status, +5 V dc status, optical output power, laser bias current, and laser temperature (via GOALN signal). The actual optical output power and laser bias values are provided to the user through a graphical interface.

---

## Third Party

---

### Description

For use with third-party network management systems, such as AM Communications and Superior Electronics products, the LLNTR may be monitored via the telemetry port on the Laser Link II Mainframe. The 25-pin connector interface is located on the power distribution board and provides non-proprietary network management signals (see mainframe user manual). The telemetry alarm parameters, vital sign designation, and DB-15 connector pin numbers are provided in the table below.

<b>Alarm Vital Sign (VS #/Pin #)</b>	<b>Description</b>	<b>Logic</b>
#1 / 5	Redundant power alarm	+5 V = alarm 0 V = normal
#2 / 11	Optical output power	Analog 1 V/10 mW
#3 / 12	Laser bias current	Analog 1 V/50 mA
#4 / 4	GOALN general alarm, $\pm 5$ V dc fault, RPAN, laser temp out of range, laser bias out of range, optical power out of range, or fan alarm	+24 V = normal 0 V = alarm

---

## Section D Troubleshooting

### Troubleshooting

---

**Overview** The LLNTR is designed for continual reliable service in a communications network. There is no recommended maintenance required to be performed on the LLNTR. Routine network preventative maintenance such as monitoring performance can be achieved from the front panel diagnostics or through element management systems such as Track Link or third party providers.

---

**Chart** Use this chart as an aid in the trouble analysis of the LLNTR. If you require assistance, call ANTEC Technical Services at 1-800-FIBER ME. Technical Service is available between 8 am and 6 pm est. Twenty-four hour emergency service is available on a callback basis within 30 minutes.

Indicator	Trouble Condition	Recommended Action
Power LED red or extinguished	Power failure	Check the +24 V A and B LED status on the user panel. <ul style="list-style-type: none"><li>• If red, replace the appropriate power supply and contact Technical Services for an RR#.</li><li>• If extinguished, check the 15-pin cable from the LLNTR to the mainframe power distribution board for +24 V. Replace as needed.</li><li>• If the cable is normal and +24 V is present, replace the LLNTR and contact Technical Services for an RR#.</li></ul>
OPTICAL POWER LED red	Optical output power is out of range	Replace the LLNTR and contact Technical Services for an RR#

---

*Continued on next page*


## Troubleshooting, Continued

Chart (continued)

<b>Indicator</b>	<b>Trouble Condition</b>	<b>Recommended Action</b>
LASER TEMP LED red	Laser temperature is out of range	If the operating environment is within normal range, replace the LLNTR and contact Technical Services for an RR#
LASER BIAS LED red	Laser bias current is out of range	Replace the LLNTR and contact Technical Services for an RR#
FAN LED red	Fan failure	The LLNTR will continue to operate properly up to 50 °C. Replace or repair as necessary. Disconnect fan by removing fan screw and power adapter. Contact Technical Services for an RR# or replacement fan.

\*\*END OF CHAPTER\*\*

**(This Page Intentionally Left Blank)**



United States  
Global Headquarters  
11450 Technology Circle  
Duluth, GA 30097 USA  
P. 678-473-2000  
F. 678-473-8454

Canada  
Toronto  
1458 Epping Road  
Burlington, Ontario L7M 1P4  
P. 905-332-5166  
F. 905-332-9630

Europe  
Milan  
C&S S.R.L.  
Strada Malaspina, 12  
20090 S. Felice-Segrate  
Milan, Italy  
P. +39-2-70301049  
F. +39-2-70301049

United Kingdom  
Watermeadow House  
Watermeadow  
Chesham, Bucks HP5 1LF  
United Kingdom  
P. +44-1494-776060  
F. +44-1494-773397

Internet  
[www.antec.com](http://www.antec.com)

Asia Pacific  
Beijing  
Unit 876  
Poly Plaza  
no. 14 Dongzhimen Nandajie  
Dongcheng District  
Beijing 100027, People' s Republic of China  
P. 86-10-6501-1876  
F. 86-10-6501-1296

Shanghai  
2004 Nanjing West Road  
Shanghai International Business Centre  
Suite 412  
Shanghai 200040  
People' s Republic of China  
P. 86-21-6248-4589  
F. 86-21-6248-1018

Hong Kong  
Unit 1814, Miramar Tower  
1-23 Kimberley Road  
TST, Kowloon, Hong Kong  
P. 852-2735-3131  
F. 852-2736-7171

Singapore  
Block 105, #09-2182  
Bedok North Avenue 4  
Singapore 460105  
P. 65-245-1175  
F. 65-245-1165

Latin America  
Miami  
8578 NW 23rd Street  
Miami, FL 33122 USA  
P. 305-592-3948  
F. 305-592-9646

Argentina  
Av. Juan de Garay 840 3 Piso  
Buenos Aires, Argentina 1153  
P. 541-300-2333  
F. 541-300-0083

Brazil  
Rua Luiz Carlos Prestes, 350  
Suite 205-206  
Barra Trade II, Barra da Tijuca  
Rio de Janeiro, RJ Brasil 22793  
P. 5521-430-8829  
F. 5521-430-8930

Venezuela  
Ave. Rio de Janeiro  
Edf. ELE - Piso 1 Ofic. No. 2  
Las Mercedes  
Caracas, Venezuela  
P. 582-993-2340  
F. 582-993-1468

Mexico  
Leona Vicario 710-A desp. 001  
Col. La Purisima  
Metepac, Edo. de Mexico  
C.P. 52140, Mexico  
P. 52-72-12-45-93  
F. 52-72-12-45-94